

Installation Instructions

To install this firmware, please follow these steps:

1. Download the update.img file
2. Use a browser to open the web interface (use the IP address of the base)
3. Go to the Firmware upgrade tab, select Firmware update option, and select the update.img file.
4. Please be patient, the upgrade process can take a long time. If you see the process like stopping around 40% this is normal the process will continue after 4 to 5 minutes.

