







ries(21700) under the temperature of 21±3°C and humidity of 50% - 80%. The true per Note: 1.According to the ANSI/PLATO FL1 standard, the above specifications are from the results produced by Fenix through its laboratory testing using two ARB-L21-6000 ba mance of this product may vary according to different working environments and the

actual utility used.

2. The stepless brightness regulation is available in all modes except for Strobe and SOS.

*The High output is measured in total of runtime including output at reduced levels due to temperature or protection mechanism in the design

**The above optical power of UV light refers to the all-wave optical power of UV light.

Do NOT shine the flashlight directly into anyone's eyes, as this flashlight is a high-intensity lighting device.

All information provided in this manual is subject to change without

prior notice.

**Do NOT place this flashlight in the reach of children!

**Do NOT place light head near flammable objects or liquids, high temperatures can cause objects to overheat and become flammable/gnite!

**Do NOT use the flashlight in inappropriate ways such as holding the unit in your mouth, doing so could cause serious personal injury or death if the flashlight or internal battery fails!

**OThis flashlight will accumulate a significant amount of heat while operating, resulting in a high temperature of the light shell. Pay close attention to avoid burns.

Take out the battery to prevent accidental activation during storage or

transportation.

'The LEDs of this flashlight are not replaceable; so the whole light will need to be replaced when any one of the LEDs reaches the end of its lifespan.

'This flashlight is for professional use only. Not for use by untrained individuals or children.

©This flashlight complies with the EU photobiological safety standard

EN 62471. Please use this flashlight according to the specified safety classification.

Warning: Ultraviolet (UV) Radiation Hazard

Warning: Ultraviolet (UV) Radiation Hazard

This flashlight emits ultraviolet (UV) radiation, which may cause damage to eyes and skin.

UV light is generally invisible to the human eye. Improper use may result in unintended exposure.

Do not look directly at the UV-LED or its beam during operation. Avoid shining the flashlight directly at people or animals.

Caution: UV radiation reflects off surfaces (e.g., mirrors, metal), increasing the risk of accidental exposure.

Be aware that obliects and liquids you shine on may redirect or reflect

Be aware that objects and liquids you shine on may redirect or reflect the light beam, depending on the kind of surface they have.

When used in close proximity to objects, reflected UV radiation is stronger and more intense than at a distance of several meters. Do not use optical lenses to focus the light beam within its emission cone

OAI/ways wear certified UV-protective goggles and skin protection during use to avoid eye and skin damage. Also avoid protonged exposure of skin or other living tissue.

©Restrict usage to professional applications only. Always power off and store securely after use.

(ENGLISH)FENIX LR35R PRO FLASHLIGHT

@10000 lumens maximum output, 500 meters maximum beam

©Utilizes four Luminus SFT 25, eight Luminus SST 25, two OSRAM GR QSSPA1.23, and one SST-10-UV, with a lifespan of 50,000 hours

each.

*Dual light source: 5000-lumen, 500-meter super bright spotlight, and 8000-lumen large floodlight.

*365 m UV light with 3.7 W of optical power for large-area, long-distance, and high-accuracy UV detection.

*Red light for night reading and protecting night vision; red flash for alerting and calling for help.

©Electronic switch for mode switching and toggle switch for stepless Proyected by two large-capacity 6000mAh 21700 batteries that provide a max runtime of 135 hours.

Universal USB Type-C port supports 18 W fast charging and fast discharging.

© Stainless steel strike bezel inlaid with three tungsten steel breaking

tips for quick window breaking

© Lockout function prevents accidental activation. © Size: 5.63" x 2.17" x 1.83"/143 × 55 × 46.5 mm

OWeight: 16.12 oz/457 g (including batteries)

OPERATING INSTRUCTIONS

Mode Switching With the light turned on: Single click the electronic switch to cycle through Spotlight mode—Floodlight mode—Spot-and floodlight mode. With the light turned off or locked: Double click the electronic switch to enter the Red light mode. Single click the electronic switch to cycle through Red light mode—Red flash mode—UV light mode. Press and hold the electronic switch for 0.5 seconds to exit the Red light mode/Red flash mode/UV light mode and turn off the light.

On/off
On: With the light locked, rotate the toggle switch clockwise to turn on the light; with the light unlocked and turned off, press and hold the electronic switch for 0.5 seconds to turn on the light.
Off: Rotate the toggle switch all the way to the counterclockwise stop or press and hold the electronic switch for 0.5 seconds to turn off the light.

Strobe & SOS Modes With the light unlocked, press and hold the electronic switch for 1.2 seconds to enter the Strobe mode. Single click the electronic switch to select between the Strobe mode and the SOS mode. Press and hold the electronic switch again for 1.2 seconds to exit the Strobe mode or the SOS mode.

Rotate the toggle switch to realize stepless brightness regulation and adjust the brightness level.

Spot-and floodlight, Red light, Red flash, and UV light modes

With the light unlocked, rotate the toggle switch all the way to the counterclockwise stop to lock the light.

With the light locked, rotate the toggle switch clockwise to unlock and turn on the light.

Intelligent Memory Circuit The flashlight automatically memorizes the last selected mode excluding Strobe and SOS.

When turned on again by rotating the toggle switch clockwise or pressing the electronic switch for 0.5 seconds, the previously used Spotlight mode, floodlight mode, or Spot-and floodlight mode will be

When turned on again by double clicking the electronic switch, the previously used Red light mode, Red flash mode, or UV light mode will

*Note: The flashlight doesn't memorize the previously used brightness level

BATTERY SPECIFICATIONS

Туре	Dimensions	Nominal Voltage	Usability	
Fenix ARB-L21 Series	21700	3.6 V	Recommended	√√
Rechargeable Battery (Li-ion)	21700	3.6 V	Caution**	!
Rechargeable Battery (Li-ion)	18650	3.6 V	Banned	×

The not mix barteries of different brands, sizes, capacities, or types.

"21700 Lion batteries are powerful cells designed for commercial applications and must be treated with caution and handled with care. Using low-quality batteries or mishandling batteries (such as short-circuiting or overheating) could

lead to combustion and jeopardize the safety of users and property. Any adverse effects resulting from the use of low-quality batteries are not covered by any Fenix warranty or liability. Using quality batteries with circuit protection will reduce the potential for combustion or explosion.

BATTERY REPLACEMENT

Unscrew the light body and insert the batteries with the anode side (+) towards the light head, then screw the light body back on. *The flashlight can be used with only one battery inserted, but the brightness is

CHARGING

1.Turn off the flashlight and open the anti-dust cover, then connect the USB Type-C end of the charging cable to the light. Connect the other end of the charging cable to a charging adapter and plug it into an

electrical dutilet.

2. When charging, the five indicators will flash green from left to right to indicate the charging status. The normal charging time is about 4 hours from depleted to fully charged.

3. The LR35R Pro automatically recognizes charging adapters that support PD3.0, PD2.0, and other mainstream fast charging protocols, as well as standard 5 V charging adapters. The maximum charging current is 3 A, and the maximum charging current is 2.5 A for a 5 V

POWER BANK FUNCTION

1. Turn off the flashlight and open the anti-dust cover. Connect the USB Type-C end of the charging cable to the light and connect the other end of the charging cable to the device.

2. When discharging, the five indicators will flash green from right to left to indicate the discharging status.

3. Once discharging is completed, be sure to unplug the cable and close the anti-fust cover.

Close the am-cust curver.

Note: When charging or discharging, the available brightness levels for the Spotlight and Floodlight range from 200 to 900 lumens; the available brightness level for the Spotlight ranges from 400 to 800 lumens; the available brightness level for the Red light ranges from 60 to 260 lumens; the Red light properties at its lowest brightness level.

BATTERY LEVEL INDICATION

With the light turned off(locked or unlocked), single click the electronic switch to check the battery status. Each time the light is turned on, the

indicator(s) will also indicate the battery level. Single click once again and the indicator(s) will go out, or without any operation the indicator(s) will last for 3 seconds. will last for 3 seconds. Five lights on: 100% - 80% Four lights on: 80% - 60% Three lights on: 60% - 40% Two lights on: 40% - 20% One light on: 20% - 1%

LOW-VOLTAGE WARNING

When the voltage level drops below the preset level, the flashlight is programmed to downshift to a lower brightness level until the lowest output is reached. When this happens in the lowest output, one battery level indicator blinks to remind users to recharge or replace the batteries in a timely manner till the battery runs out.

INTELLIGENT BRIGHTNESS DOWNSHIFT FUNCTION Intelligent downshift

When the light head is close to an illuminated object (about 2.36"/60 mm) for more than 1.5 seconds, the flashlight will automatically downshift to 50 lumens to avoid potential danger/burns caused by high temperatures. When the light head is away from the illuminated object for more than 0.8 seconds, the flashlight automatically recalls the previously used brightness level.

On/off
With the light locked, press and hold the electronic switch for 6 seconds, and the flashlight will blink twice on the Low output(50 lumens) of the Floodlight mode, indicating that this function is enabled. With the light locked, press and hold the electronic switch for 6 seconds, and the flashlight will blink 6 times on the Low output(50 lumens) of the Floodlight mode, indicating that this function is disabled.

INTELLIGENT OVERHEAT PROTECTION

pendos, when the liashinght reaches a temperature of 55 °C/131° F of above, it will automatically step down a few lumens to reduce the temperature. When the temperature drops below 55 °C/131 ° F, the flashlight will gradually recall the preset output level.

USAGE AND MAINTENANCE

© Disassembling the sealed head can cause damage to the light and will void the warranty.

OFenix recommends using excellent quality batteries Off the light will not be used for an extended period, remove the batteries, or the light could be damaged by electrolyte leakage.

OLock the light, unscrew the light body half a turn or take out the batteries to prevent accidental activation during storage or transporta-

"Olong-term use can result in O-ring wear. To maintain a proper water seal, replace the ring with an approved spare.

O Periodic cleaning of the light and battery contacts improves the light's performance as dirty contacts may cause the lamp to flicker, shine intermittently or ven fail to illuminate for the following reasons.

A: The flashlight is locked Solution: Rotate the toggle switch clockwise to unlock and turn on the

Solution: Recharge or replace the batteries.
C: The contact or contact point of the batteries or flashlight is dirty.
Solution: Clean the contact points with a cotton swab soaked in rubbing alcohol.

If the above methods don't work, please contact the distributor

INCLUDED Fenix LR35R Pro flashlight, 2 x ARB-L21-6000 batteries, USB Type-C charging cable, Holster, Lanyard, Spare O-ring, User manual, Warranty