


**FENIX™****FENIX™**

## Fenix E15

Fenix E15 is a universal EDC flashlight. Offering 3 brightness levels, it can meet various requirements of the brightness and the runtime perfectly. The portable and compact design makes it extremely convenient to be carried. It performs well in the cold areas due to the anti-freezing lithium battery. Thanks to the advanced constant brightness technology and waterproofing to the IPX-8 Standard, E15 must be able to satisfy your needs in different outdoor conditions and in emergency.



# E15

**Max 170 Lumens****User manual***Illuminate Your Adventure*

### Technical Parameters

ANSI / NEMA FL1	High	Mid	Low
OUTPUT	170 Lumens	80 Lumens	11 Lumens
RUNTIME	1h 51min	4h 33min	36h
DISTANCE	102m (Max)		
INTENSITY	2993cd (Max)		
IMPACT RESISTANT	1 m		
WATERPROOF	IPX-8, underwater 2m		
ACCESSORIES	Key ring and spare O-ring		

\*The flashlight will drop down into Mid output after working about 15 minutes in High output. Therefore, the runtime of High output is an accumulated time.

- Cree XP-E LED with a lifespan of 50,000 hours
- Uses one 3V CR123A Lithium battery
- 59.6mm (Length) x 19.7mm (Diameter)
- 23-gram weight (excluding battery)
- Digitally regulated output - maintains constant brightness
- Reverse polarity protection, to protect from improper battery installation
- Reliable twisty switch
- Capable of standing up securely on a flat surface to serve as a candle
- Made of durable aircraft-grade aluminum
- Premium Type III hard-anodized anti-abrasive finish
- High-efficiency total reflection lens

Note: The above-mentioned parameters (Lab-tested by Fenix using high-quality CR123A Lithium battery) are approximate and may vary between flashlights, batteries and environments.

### Operation Instruction

Screw the light head to turn it on and unscrew it to turn it off.

Turn off the light and turn it on again within two seconds, it will select the brightness level in the order of Mid→Low→High→Cycle.

If the off-time is over two seconds, when turn on again, it will enter into the Mid brightness level.

### Battery Specifications

Type	Dimensions	Nominal Voltage	Usability	
Non-rechargeable Battery (Li-thium)	CR123A	3V	Usable	✓
Rechargeable Battery (Li-ion)	16340	3.7V	Banned	✗

\*Please do not use the banned batteries, or it will cause damage to the flashlight.

### Battery Replacement

Unscrew the light head to put in the battery with the anode (+) toward the light head, screw the light head back on.

### Usage and Maintenance

- Please don't disassemble the sealed head, doing so can cause damage to the flashlight and will void the warranty.

### Product Registration

We kindly suggest that you register your product on the official website of Fenixlight Limited(www.fenixlight.com). You' ll receive an extra six months of warranty coverage once you have successfully registered. By participating in an optional customer survey, you are entered in a drawing for free Fenix products.

### Warning

**E15 is a high-intensity lighting device and capable of causing eye damage, avoid shining the light directly into the eyes.**

- Please use battery of high quality, and take out the battery if you do not use the flashlight for a long time, or the flashlight could be damaged by electrolyte leakage or battery explosion which is caused by low quality battery.

- The O-ring may be worn out after using for a long time. If it happens, please replace the O-ring with a new one to keep the flashlight properly sealed against water.
- Please clean the contacts of your light from time to time, especially if the light flickers or doesn't light up. There may be several reasons for a flickering or not working light:

**Reason A:** The battery needs replacing.

**Solution:** Replace the battery (Please confirm the correct installation of anode and cathode).

**Reason B:** The threads PCB board contact or other contacts are dirty.

**Solution:** Clean the contact points with an alcohol soaked cotton swab. If the above methods don't work, please contact your distributor and refer to the warranty policy.

### Product Warranty

We will replace products afflicted with manufacturing defects within 15 days of purchase and repair a light free of charge within 24 months of purchase if problems develop with normal use; if repair is required after 24 months from the date of purchase, we will charge for parts. The total repair fee is dictated by the cost of the replaced materials.