



User Manual




E35 Ultimate Edition

Max 900 Lumens

Fenix E35 Ultimate Edition

From 900-lumen Burst mode to the energy-conserving Low mode (10 lumens), the E35 Ultimate Edition outdoor flashlight gives you total control over output and runtime. Besides rechargeable 18650 Li-ion battery, this dual-fuel capable light also works with CR123A primary lithium battery. When it comes to user-interface, the all-function side switch is all you need for ON/OFF, output selection and instant burst.



- ✦ Cree XM-L2 U2 LED with a lifespan of 50,000 hours
- ✦ Uses one 18650 rechargeable Li-ion battery or two 3V CR123A Lithium batteries
- ✦ 130mm (Length) x 24mm (Diameter)
- ✦ 72-gram weight (excluding batteries)
- ✦ Digitally regulated output - maintains constant brightness
- ✦ Reverse polarity protection guards against improper battery installation
- ✦ Anti-roll, slip-resistant body design
- ✦ Side switch on the head for simple and convenient operation
- ✦ Capable of standing up securely on a flat surface to serve as a candle
- ✦ Made of durable aircraft-grade aluminum
- ✦ Premium Type III hard-anodized anti-abrasive finish
- ✦ Toughened ultra-clear glass lens with anti-reflective coating

Technical Parameters

ANSI/NEMA FL1	General Mode			Burst
	High	Mid	Low	
OUTPUT	360 Lumens	120 Lumens	10 Lumens	900 Lumens
RUNTIME	3h	11h	140h	/
DISTANCE	156m (Max)			
INTENSITY	6100cd(Max)			
IMPACT RESISTANT	1 m			
WATERPROOF	IPX-8, underwater 2m			
ACCESSORIES	Lanyard, spare O-ring			

Notice: The above-mentioned parameters (lab tested by Fenix using an ARB-L2 Li-ion battery) are approximate and may vary between flashlights, batteries and environments.

Operation Instruction

ON/OFF

Press and hold the switch for 0.5 seconds to turn the light on or off.

Output Selection

With the light on, press the switch to select the brightness level in the order of High→Low→Mid.

Burst Mode

Press and hold the side switch for one second to activate the Burst mode even if the light is off. When the switch is released, the light will return to the previous condition.

Intelligent Memory Circuit

The light remembers the last used brightness level when the light is turned off and then on again.

Battery Replacement

Unscrew the light head to put in the battery with the anode (+) toward the light head, screw the light head back on to test.

Battery Specifications

Type	Dimensions	Nominal Voltage	Usability	
Fenix ARB-L2	18650	3.7V	Recommended	✓
Non-rechargeable Battery (Lithium)	CR123A	3V	Recommended	✓
Rechargeable Battery (Li-ion)	16340	3.7V	Banned	✗
Rechargeable Battery (Li-ion)	18650	3.7V	Cautious*	!
Rechargeable Battery (LiFePO4)	16340	3.2V	Usable	✓
Rechargeable Battery (LiFePO4)	18650	3.2V	Banned	✗

Warning: Please do not mix batteries of different brands, size, capacity or type. Doing so may cause damage to the flashlight or the batteries being used.

*18650/16340 Li-ion batteries are powerful cells designed for commercial applications and must be treated with caution and handled with care. Quality batteries with circuit protection will reduce the potential for combustion or explosion but cell damage or short circuiting are potential risks the user assumes.

Usage and Maintenance

- ✦ Please don't disassemble the sealed head, doing so can cause damage to the flashlight and will void the warranty.
- ✦ Please use batteries of high quality, and take out the battery if you do not use the light for a long time, or the light can be damaged by electrolyte leakage or battery explosion.
- ✦ Unscrew the tail cap one-half turn or take out the battery to prevent accidental activation during storage or transport.
- ✦ The O-ring may be worn out after long-term use. If it happens, please replace the O-ring with a new one to keep the flashlight properly sealed against water.
- ✦ Please clean the contacts of your light from time to time, especially if the light flickers or doesn't light up. There are several reasons for a flickering or not working light:

Reason A: The batteries need replacing.

Solution: Replace the batteries (Please confirm the correct installation of anode and cathode).

Reason B: The threads, PCB board contact or other contacts are dirty.

Solution: Clean the contact points with an alcohol soaked cotton swab.

If the above methods don't work, please refer to the warranty policy before contacting your authorized distributor.

Product Warranty

We will replace products afflicted with manufacturing defects within 15 days of purchase and repair a light free of charge within 24 months of purchase if problems develop with normal use; if repair is required after 24 months from the date of purchase, we will charge for parts. The total repair fee is dictated by the cost of the replaced materials.

Product Registration

We kindly suggest that you register your product on the official website of Fenixlight Limited (www.fenixlight.com). You'll receive an extra six months of warranty coverage once you have successfully registered. By participating in an optional customer survey, you are entered in a drawing for free Fenix products.

Warning

E35 is a high-intensity lighting device and capable of causing eye damage, avoid shining the light directly into the eyes.