



UC30

Max 960 Lumens

User manual

Illuminate Your Adventure

Fenix UC30 Flashlight

The Fenix UC30 rechargeable flashlight combines high intensity with reliable Micro-USB charging in a go-anywhere size. The side switch on the head is all you need for output selection. Featuring 960-lumen maximum output from a 18650 battery, the UC30 offers five outputs including strobe mode to cover from daily use to outdoor and professional use.

- ✦ Cree XM-L2 (U2) LED with a lifespan of 50,000 hours
- ✦ Uses one 18650 rechargeable Li-Ion battery or two 3V CR123A Lithium batteries
- ✦ Micro-USB charging
- ✦ 130mm (Length) x 25.4mm (Diameter)
- ✦ 126-gram weight (excluding battery)
- ✦ Digitally regulated output - maintains constant brightness
- ✦ Low-voltage warning function to remind you to replace the battery
- ✦ Reverse polarity protection guards against improper battery installation
- ✦ Over-heat protection to avoid high-temperature of the surface
- ✦ Anti-roll, slip-resistant body design
- ✦ Side switch on the head for output selection
- ✦ Made of durable aircraft-grade aluminum
- ✦ Premium Type III hard-anodized anti-abrasive finish
- ✦ Toughened ultra-clear glass lens with anti-reflective coating

Technical Parameters

ANSI/NEMA FL 1	Turbo	High	Mid	Low	Strobe
OUTPUT	960 lumens*	400 Lumens	110 Lumens	10 Lumens	960 Lumens
RUNTIME	1h10min **	3h	11h	120h	/
DISTANCE	204m(Max)				
INTENSITY	10404cd(Max)				
IMPACT RESISTANT	1m				
WATERPROOF	IPX-5, underwater 2m***				
ACCESSORIES	USB cable, holster, lanyard, spare O-ring and two USB anti-dust plugs				

Notice: The above-mentioned parameters [lab-tested by Fenix using 3500mAh ARS-L2 18650 rechargeable Li-Ion battery] are approximate and may vary between flashlights, batteries and environments.
 * When powered by two CR123A batteries, the Turbo output will be around 1000 lumens for the first couple of minutes.
 ** The flashlight will drop down into the high brightness level after working about 5 minutes in the Turbo mode. Therefore, the runtime of Turbo output is an accumulated time.
 ***The covered Micro USB port maintains waterproof.

Operation

ON/OFF

Press and hold the side switch on the head for over 0.5 seconds to turn the flashlight on/off.

Mode Selecting

With the light on, press the side switch to cycle through four different brightness levels in the order of Turbo → Low → Medium → High.

Strobe

Press and hold the side switch for 1 second to enter into strobe mode. A single press on the side switch will return the flashlight to general mode from strobe.

Intelligent Memory Circuit

The Fenix UC30 memorizes the last brightness level used in the general mode, but it will not remember the strobe mode. The next time you turn the flashlight on, it will activate the last brightness level you selected.

Turbo Output

In Turbo output, the LED runs at the highest brightness and discharge rate. Use of high quality batteries is recommended for peak performance. As a high-performance light, the UC30 accumulates significant heat while at Turbo output. To protect the light and user, the

UC30 automatically drops down into the High brightness level after running at Turbo output for about three minutes. If further Turbo output is needed, reset the light with the side switch. Be advised that prolonged Turbo output may reduce the UC30's life span or cause permanent damage to the light.

Low-voltage Warning Function

When the voltage level drops below the preset level, the UC30 is programmed to downshift to a lower brightness level. When this happens in Low output mode, the flashlight blinks three times every five minutes to remind you to replace the battery.

Charging

1. Turn off the flashlight, remove the anti-dust plug in the front of the UC30 to reveal the charging port and plug the Micro-USB end of the USB cable into the light's charging port.
2. Press the tail switch to start the charging process. And the indicator light turns red to indicate the charging process has begun. The indicator turns solid green when the battery is fully charged, it takes about 3.5 hours to fully charge a 2500mAh Li-Ion 18650 battery (lab-tested by Fenix using ARS-L2 rechargeable Li-Ion battery).
3. Once charging is completed, press the tail switch to stop the charging process and disconnect the USB cable from the light and be sure to secure the anti-dust plug cover.

4. Please recharge a stored UC30 every four months to maintain optimum performance of the battery and maximize charging levels.
5. It will be okay to turn on the UC30 or change the brightness levels during the charging process, but doing so will extend the charging time and the flashlight cannot enter into Turbo output or strobe mode in this case.

Battery Specifications

Type	Dimensions	Nominal Voltage	Usability	
Fenix ARS-L2 Series	18650	3.6V/3.7V	Recommended	✓
Non-rechargeable Battery (Lithium)	CR123A	3V	Usable	✓
Rechargeable Battery (Li-Ion)	16340	3.6V/3.7V	Banned	✗
Rechargeable Battery (Li-Ion)	18650	3.6V/3.7V	Cautious*	!
Rechargeable Battery (LiFePO4)	16340	3.2V	Banned**	✗
Rechargeable Battery (LiFePO4)	18650	3.2V	Banned**	✗

Warning

1. Please do not mix batteries of different brands, size, capacity or type. Doing so may cause damage to the flashlight or the batteries being used.
 2. Do not use the UC30 flashlight to charge the banned batteries, or it may cause explosion.
- *18650 Li-Ion batteries are powerful cells designed for commercial applications and must be treated with caution and handled with care. Quality batteries with circuit protection will reduce the potential risk for combustion or explosion but cell damage or short circuiting are potential risks the user assumes.
 ** The UC30 can be powered by using 18650/16340 LiFePO4 rechargeable battery, but using the flashlight to charge them may cause damage or even explosion to the battery. To avoid the potential danger, please do not charge these two kinds of batteries.

Battery Replacement

Unscrew the tail cap to insert the batteries with the anode side (+) toward the light's head, then screw the tail cap back on.

Usage and Maintenance

- ✦ Please don't disassemble the sealed head, doing so can cause damage to the flashlight and will void the warranty.
- ✦ We recommend the use of high quality battery. If the flashlight is not to be used for an extended period, remove the battery, or the flashlight could be damaged by electrolyte leakage or battery explosion.
- ✦ Due to the momentary-on tactical switch, the flashlight may be accidentally activated when stored, transported or placed in a pocket. Unscrew the tail cap one-half turn or take out the battery to avoid unwanted operation.

✦ The O-ring or USB anti-dust plug may be worn out after using for a long time. If this happens, please replace the O-ring or USB anti-dust plug with a new one to keep the flashlight properly sealed against water.

✦ Please clean the contacts of your light from time to time, especially if the light flickers or doesn't light up. There may be several reasons for a flickering or not working light:

Reason A: The battery needs replacing.
Solution: Replace the battery (Please confirm the correct orientation of positive and negative ends).

Reason B: The threads, PCB board contact or other contacts are dirty.
Solution: Clean the contact points with an alcohol soaked cotton swab.

If the above methods don't work, please refer to the warranty policy.

Product Warranty

We will replace products with manufacturing defects within 15 days of purchase and repair a light free of charge within 24 months of purchase if problems develop with normal use; if repair is required after 24 months from the date of purchase, we will charge for parts. The total repair fee is dictated by the cost of the replaced materials.

Product Registration

We kindly suggest that you register your product on the official website of Fenixlight Limited (www.fenixlight.com). You'll receive an extra six months of warranty coverage once you have successfully registered. By participating in an optional customer survey, you are entered in a drawing for free Fenix products.

Warning

UC30 is a high intensity lighting device capable of causing eye damage. Avoid shining the light directly into anyone's eyes.